# Crestaform Durable

#### Introduction

The Crestaform® Durable is a durable 3D printing resin for elastic prototyping, Nylon-like materials. It exhibits high impact resistance, which together with elasticity, creates a perfect 3D printing resin for applications where impact resistance is crucial. Crestaform Durable also has increased fracture toughness.

### Crestaform® Durable comes with the following benefits:

- Excellent mechanical performance
- High reactivity and printing speed
- Rigorously tested to ensure optimal performance
- Globally available technical support
- Reputable manufacturer with over 100 years of experience and expertise

### Typical printing parameters\*

Printer Type	LCD, DLP		
Printer Wavelength (nm)	385 - 405		
Layer Height (μm)	25 - 100		
Printing Temperature (°C)	21 - 30		
Base Layer Exposure Time (sec)	10 - 30		
Normal Layer Exposure Time (sec)	1.5 - 2.5		

<sup>\*</sup> For DLP printers, it is recommended that light power is reduced to around 2.5mW/cm<sup>2</sup>

#### Recommended cleaning

- Soak the print in a clean isopropanol (IPA) (or similar solvent) bath for a minimum of 5 minutes. Alternatively, rinse the part with IPA until all the visible uncured resin has been removed. Reusing IPA in multiple cleans can reduce the cleanliness and clarity of a print.
- Leave the print to dry off any residual solvent prior to post-curing

#### Recommended post-curing

- Post-cure as soon as possible after completion of printing
- To reduce surface tack, it is recommended to post-cure Crestaform Durable at 60°C for 1 hour in combination with UV post-curing
- If a hybrid thermal-UV post-cure station is not available. Undertake UV post-curing first and then use a standard thermal oven (non-domestic) to obtain final properties

#### Instructions to use the Crestaform® Durable resin:

- Always shake or mix the resin thoroughly before use
- Open the container and pour the appropriate amount of resin into the tank according to the size of the printer model
- Make sure to not spill the resin onto the printer, LCD screen or anywhere outside of the resin tank
- If not used for a long time, please filter the resin and pour the resin into the storage container







## **Physical properties**

	Values	Description
Viscosity (Poise)	7.0 – 9.0	ICI Viscosity @ 25°C
Liquid Density (g/cm³)	1.12 – 1.13	
Colour Options	-	Black, Blue, Grey

### **Mechanical properties**

Typical properties below: Mechanical Testing Specimen Print Orientation - 50°

	Values	Description				
Tensile strength (MPa)*	37	ISO 527-2 Type 5A				
Tensile modulus (GPa)*	1.5	ISO 527-2 Type 5A				
Elongation at break (%)*	57	ISO 527-2 Type 5A				
Flexural strength (MPa)*	28	ISO 178				
Flexural modulus (GPa)*	0.5	ISO 178				
Izod Impact Strength (kJ/m²)**	6.3	ISO 180 Type A				
Hardness (Shore)*	71D	ISO 868				
Heat deflection temperature (°C)*	33	ISO 75-2, Method A (1.8 MPa)				

<sup>\* 60</sup> mins at 60°C + 405nm UV Post Cure for cured properties

### **Chemical Resistance\***

	Concentration	Mass increase (%)			
	Concentration	1 day	7 days	14 days	28 days
Sodium Hydroxide	33%	3**	3	2	***

<sup>\*</sup> Testing Conducted at 40°C using 1cm3 cubes

<sup>\*\* 16</sup> mins at 60°C + 405nm UV Post Cure for cured properties

<sup>\*\*</sup> Slightly swollen

<sup>\*\*\*</sup> Surface degradation





### **Compatibility**

Crestaform® Durable has been designed to work with any UV LCD and DLP 3D printer that is open to 3<sup>rd</sup> party resins, including, but not limited to:

- Anycubic
- Elegoo
- Phrozen
- Creality
- Asiga



#### Dο

- Always wear Personal Protection Equipment (PPE), protective eyewear and chemical nitrile gloves when handling resin
- Shake the resin well every time before you use it or decant from the container
- If spilled, please clean the spill immediately with paper towel, and Isopropanol (IPA)
- Store it in its original container at room temperature, away from children, untrained personnel, direct or indirect sunlight, heat sources, sparks and open flames
- Use it in well ventilated rooms
- Use every sensible preventive precaution to avoid skin contact, spillage of resin, eye contact or swallowing. Make note of Local Poison Centres availability

## X Do not

- Expose resin to direct or indirect sunlight, UV light, heat sources, sparks and open flame while handling and storing the resin
- Touch the resin with bare hands. Always wear appropriate gloves. If skin contact occurs, wash it with soapy water. If you feel unwell, please consult immediately medical assistance
- Swallow the resin or printed objects
- Expose to children or pets
- Handle before completing training
- Expose persons sensitive to the resin components please see Material Safety Datasheet
- Inhale the resin fumes. Use only in well ventilated rooms or areas
- Pour the resin or used IPA into the draining system

#### **Storage**

Crestaform® Durable should be stored in the dark, in suitable, closed containers. It is recommended that the storage temperature should be between 15°C and 35°C. Ideally, containers should be opened only immediately prior to use. Keep out direct light/sunlight.

### **Packaging**

Crestaform® Durable is supplied in 1000 g bottles. Bulk supply available.

#### Health and safety

Please see separate Safety Data Sheet.

@ 2021 Scott Bader Company Limited, May 2023, Issue No. 2

All information on this data sheet is based on laboratory testing and is not intended for design purposes. Scott Bader makes no representations or warranties of any kind concerning this data. Due to variance of storage, handling and application of these materials, Scott Bader cannot accept liability for results obtained. The manufacture of materials is the subject of granted patents and patent applications; freedom to operate patented processes is not implied by this publication.

