

## GELCOAT APPLICATION CHECKLIST

The following table shows a summary of points leading to good consistent application of gelcoat to a mould in a production environment.

<b>Gelcoat Storage</b>	<ul style="list-style-type: none"> <li>• Keep gelcoat stored in original containers at appropriate temperature (~20°C is ideal).</li> <li>• Ensure good stock rotation. <i>(The older a gelcoat is, the more the low shear viscosity will have drifted, and the more prone the gelcoat will be to sagging.)</i></li> <li>• Mix the gelcoat in the keg/drum before decanting.</li> </ul>
<b>Workshop &amp; Mould Preparation</b>	<ul style="list-style-type: none"> <li>• Where possible, keep the workshop and mould temperature to ambient (around 20°C is ideal).</li> <li>• Ensure that the mould is clean, dry and an appropriate release agent has been correctly applied.</li> </ul>
<b>Gelcoat Weighing &amp; Addition of Catalyst</b>	<ul style="list-style-type: none"> <li>• Ensure that the weighing area is clean and free from contaminants.</li> <li>• Accurate weighing of the gelcoat is required for catalyst dosing to be accurate.</li> <li>• Keep different coloured gelcoats well apart.</li> <li>• Add the correct (and consistent) amount of the correct catalyst to each portion of gelcoat.</li> <li>• Mix the catalyst into the gelcoat thoroughly with clean mixing apparatus before application begins.</li> </ul>
<b>Gelcoat Application</b>	<ul style="list-style-type: none"> <li>• Avoid pouring the gelcoat onto the mould surface. This will leave a colour fault on the demoulded surface.</li> <li>• Always use a clean brush, roller or recently cleaned spray equipment.</li> <li>• Avoid excessive thickness in one application. This will lead to slumping and/or tearing.</li> <li>• Minimise drips and runs wherever possible (through applying at correct thickness).</li> <li>• Avoid very thin application (&lt;200µm) as this will lead to poor cure.</li> <li>• The film must not be disturbed once cure has begun (time will be dependent on catalyst level and temperature of application).</li> </ul>
<b>Brush Application</b>	<ul style="list-style-type: none"> <li>• Apply the gelcoat by brush in at least two directions. This helps to reduce the effect of brush-marking.</li> <li>• Good brushing improves the air release in a gelcoat layer <i>(the air release additive used in brush gelcoats relies on shear to work)</i>.</li> <li>• Laying off with a brush will help to remove air.</li> </ul>
<b>Spray Application</b>	<ul style="list-style-type: none"> <li>• Spray application will help to eliminate variations in thickness and give a more consistent gelcoat film.</li> <li>• It is important that the spray equipment is set up to give a good fan to achieve the optimum spray pattern.</li> <li>• Spray in even passes in a number of directions until the required thickness.</li> </ul>
<b>Application of the Backing System</b>	<ul style="list-style-type: none"> <li>• The back surface of the gelcoat must be kept clean and free from dust and moisture until the backing system is applied.</li> <li>• The backing system should only be applied after the gelcoat film is sufficiently cured.</li> <li>• Good consolidation of the backing system is vital to avoid blistering issues.</li> </ul>