

# CRYSTIC® 1-301PA

## Low Viscosity Low Exotherm General Purpose Polyester Resin

#### Introduction

Crystic 1-301PA is an orthophthalic, low viscosity unsaturated polyester resin. It is supplied as a solution dissolved in monomeric styrene. It is pre-accelerated to give sufficient pot life for contact moulding using Andonox® KP9 catalyst at normal ambient temperatures. It has been formulated with a special colour change mechanism for indicating the correct addition of catalyst. It is suitable for a wide range of applications.

#### **Applications**

Crystic 1-301PA is designed for application by spray, roller or brush, for contact moulding. Its thixotropy will prevent draining when used on vertical or inclined surfaces with chopped strand mat. It requires only the addition of catalyst to start the curing reaction and is therefore ideal for long production runs under controlled workshop conditions. It has a low exotherm temperature, which allows laminates up to 3mm in thickness to be laid up in one operation without excessive heat being generated.

Crystic 1-301PA has been formulated to give a tough resilient laminate. It can be used with confidence in the construction of industrial and general-purpose mouldings.

#### **Formulation**

Crystic 1-301PA is formulated for room temperature curing applications. It requires only addition of the correct amount of catalyst to start the curing reaction. The recommended formulation is given in Table 1.

Table 1: Formulations for room temperature curing of Crystic 1-301PA

Component	Parts by weight
Crystic 1-301PA	100
Catalysts Andonox® KP9 or Norox® MEKP 925H	1.0-3.0

The catalyst must be stirred thoroughly into the resin shortly before use. Curing should not be carried out at temperatures below 15°C. Scott Bader (Pty) Ltd. will not be liable for problems caused by use at lower temperatures than recommended. The resin must be allowed to attain workshop temperature (15-30°C) before being formulated for use.

Crystic 1-301PA has a built in chemical colour change mechanism to indicate to operators that the catalyst has been incorporated into the resin. Table 2 shows how the colour changes with time.

Table 2: Catalyst colour indicator operation time for Crystic 1-301PA

Time after catalyst addition	Colour
0 minutes	Blue
1-5 minutes	Green
10-15 minutes	Pink

N.B. Peroxide catalysts are highly reactive and may decompose with explosive violence, or cause fires, if they come into contact with flammable materials, metals or accelerators. For this reason they must never be stored in metal containers or be mixed directly with accelerators.

Crystic 1-301PA - TDS 1/3

The temperature and the amount of catalyst control the gel time of the resin formulation and can be approximately determined from Table 3.

Table 3: Geltimes in minutes for Crystic 1-301PA

= combination not recommended.

Catalyst type	Catalyst type Andonox <sup>®</sup> KP9		9	Norox <sup>®</sup> MEKP 925H			
Catalyst addition		3.0%	2.0%	1.0%	3.0%	2.0%	1.0%
2	35°C		7	9	6	10	20
mperatur	25°C		10	17	11	25	57
Tem	15°C	16	20				

Crystic 1-301PA is formulated for use between 15°C and 25°C. It is recommended that workshop temperatures be maintained within this range.

At temperatures above 30°C, the gel time even at 1% Andonox® KP9 catalyst can be so short that there is insufficient working time to use up all the resin that has been mixed. If the resin has been applied by spray, it may start to gel before the laminate can be properly consolidated. In such cases, do not use less than 1% catalyst as this can cause undercure. Rather use Norox® MEKP-925H. If using 1% of the Norox® MEKP 925 H catalyst still gives too short a working time, do not use less than this. Rather mix smaller quantities of resin at a time so that it can all be used within the working time available, or if spraying, apply smaller areas at a time.

At temperatures below 15°C, the curing reaction can be so slow that there is a high probability of undercure of the resin, even with over 3% Andonox® KP9 catalyst. Do not use more than 3% catalyst as that will not speed up the geltime appreciably or result in a faster cure; in fact it can further retard the cure. Rather warm up the resin and working area so that it is above 15°C.

Crystic 1-301PA is formulated for use under South African winter conditions. In warmer weather, users should change to Crystic 2-301PA. This has similar physical properties to Crystic 1-301PA, but its gel and cure properties are adjusted for use in warmer conditions. It also has low styrene emission. The use of low styrene emission resins is not recommended in cold conditions, and as the vapour pressure of styrene is lower at cold temperatures, it does not usually present a problem.

#### **Pigments and Fillers**

Crystic 1-301PA may be pigmented with up to 5 percent of Crystic Pigment Paste, although lesser amounts are normally sufficient in a laminating resin. Pigment pastes and fillers should be used with caution, as they are likely to have a significant effect on the storage stability, geltime and cure of the resin system, and the physical strength properties of the final product.

#### **Post Curing**

For most applications, where the moulded product will be used at ambient temperatures, satisfactory laminates can be produced without post curing at elevated temperatures, provided workshop temperatures are not below 20°C.

For more critical applications, where optimum properties are required, or where the service temperature of the moulding will be above ambient temperature, post curing at elevated temperature is recommended. The optimum temperature for Crystic 1-301PA is 80°C. After release from the mould, laminates should be allowed to mature for 24 hours at a workshop temperature of not less than 20°C. before being post cured. Place the part in an oven, suitably supported to prevent warping, and increase the temperature from ambient to 80°C in 10°C stages.

Leave the moulding at 80°C for three hours, and then switch the oven off. Allow the moulding to cool slowly in the oven. Post curing is most effective if it is carried out immediately after the 24-hour maturing period.

**Crystic 1-301PA - TDS** 2/3

#### **Liquid Properties**

The most important typical liquid properties of Crystic 1-301PA are given in Table 4.

Table 4: Typical properties of Crystic 1-301PA liquid resin

Property	Units	Nominal value 350	
Viscosity at 25°C: Brookfield RVT at 100rpm	centipoise		
Thixotropic index	ratio	2.0	
Specific Gravity at 25°C		1.08	
Acid Value	mgKOH/g	22.2	
Volatile Content	%	40	
Colour	visual	Blue	
Stability at 25°C	months	3	
Geltime at 25°C using 1% Andonox® KP9 catalyst	minutes	17	

#### **Storage**

Crystic 1-301PA should be stored in the dark in suitable closed containers. It is recommended that the storage temperature should be less than 20°C where practical, but should not exceed 30°C. Ideally, containers should be opened only immediately prior to use. Where they have to be stored outside, it is recommended that drums be kept in a horizontal position to avoid the possible ingress of water.

#### **Packaging**

Crystic 1-301PA is supplied in 25kg kegs, 225kg drums, and 1125kg intermediate bulk containers. Bulk supplies can be delivered by road tanker.

#### **Health and Safety**

Please see the applicable Material Safety Data Sheets, depending on the curing system used.

Technical Leaflet No. SBPTY026.9

Version 2: February 2013

All information on this data sheet is based on laboratory testing and is not intended for design purposes. Scott Bader makes no representations or warranties of any kind concerning this data. Due to variance of storage, handling and application of these materials, Scott Bader cannot accept liability for results obtained. The manufacture of materials is the subject of granted patents and patent applications; freedom to operate patented processes is not implied by this publication.

### **SCOTT BADER COMPANY LIMITED**

Wollaston, Wellingborough, Northamptonshire, NN29 7RL

Telephone: +44 (0) 1933 663100 Facsimile: +44 (0) 1933 666623

www.scottbader.com

Crystic 1-301PA - TDS 3/3